Bluetooth Stereo Headset

RF-MAB2



QUICK SETUP GUIDE

Congratulations on your purchase of the Rocketfish Mobile Bluetooth Stereo Headset. Listen to music wirelessly with Bluetooth audio devices and answer phone calls hands-free. You can use the headset to answer and make calls and to play music stored on your cell phone.

Features



Package contents

- Bluetooth Stereo Headset
- A/C wall adapter
- USB charging cable
- *Quick Setup Guide*
- *User Guide*

Turning the headset on and off

- To turn the headset on or off, press and hold the **Power** button for three seconds.

Pairing the headset

1 Turn off the headset, then press and hold **Talk** for six seconds. Pairing mode is activated.

2 On your cell phone, select **RF-MAB2** from the list of discovered Bluetooth devices, then enter the password **0000** to pair the headset. For more information on pairing Bluetooth devices to your cell phone, see the phone's documentation.

Note: After your headset has been successfully paired with your cell phone, the headset will automatically connect to the phone the next time the headset is turned on near the phone.

Making phone calls

To:	Do this:
Voice dial	Press **Talk** once. (Some phones might not support this feature.)
Redial	Press **Talk** twice.
Answer a call	Press **Talk** once.
End a call	Press **Talk** once.
Refuse a call	While your phone is ringing, press **Play/Pause**.
Change the volume	Press **+** or **–** .
Transfer a call between connected devices	Double-click **Talk**.

Playing music

To:	Do this:
Play/Pause	Press ▶|| to launch the phone's MP3 player and begin playing music. Press ▶|| to pause and resume playback. Press and hold ▶|| stop playback.
Select a song	Press and release ◀◀ or ▶▶.
Rewind or fast forward a song	While music is playing, press and hold ◀◀ or ▶▶. (Some phones may not support this feature.)
Answer a call while playing music	Press **Talk**, or press ▶|| to reject the call. Press **Talk** again to end the call. Music resumes playing after a call is rejected or ended.
Change the volume	Press + or – .

Using 3D sound

To enable 3D sound while in music playback mode, press ▶|| twice to select the next 3D sound effect from the available effects. Five types of 3D sound effects are programmed in the order below.

- **Normal**—No 3D sound effect. (Two beeps indicate Normal mode.)
- Provides a comfortable and persistent listening environment by removing distracting sounds.
- LIVE Delivers a natural and soft 3D sound field effect simulating that of a live performance.
- WIDE Provides a panoramic 3D audio image of widely spread main vocal and center-placed instruments.
- MEX Delivers a wide stereo sound image and but enhances low-frequency sound to provide rich and deep bass tones.

Resetting the headset

- To reset the headset, press **Play**, **Talk**, and **Volume up** simultaneously.

LED indicator messages

Headset Status	LED Status
Power on	Blue LED is on
Turning off	Red LED dims and disappears
Low battery	Red LED blinks continuously
Recharging	Red LED stays on
Recharging complete	Blue LED stays on
Pairing mode	Blue and red LEDs flash rapidly
Connection complete	Blue LED blinks every two seconds
Receiving a call	Blue LED flashes rapidly
Talking on the phone	Blue LED brightens and dims repeatedly

Specifications

Bluetooth version: 2.1
Supported profiles: A2DP, AVRCP, HFP, HSP
Frequency spectrum: 2.4~2.4835 GHz
Working distance: Maximum 33 feet (10 m)
Operating temperature: 14~140° F (-10 ~ 60° C)
Operating time: Voice: 14 hours; music: 12 hours
Standby time: 340 hours
Size: 6 × 5.4 × 2.4 inches (153 × 138 × 60 mm)
Weight: 1.9 oz (54 g)
Average charging time: 3 hours

Notes

For specifications, legal notices, warranty, and instructions for multiple Bluetooth pairings, see your online *User Guide*.

Tell us what you think!
Please go to www.bestbuy.com
and write your review for this product.

© 2009 Best Buy Enterprise Services, Inc. Distributed by Best Buy Purchasing, LLC
7601 Penn Avenue South, Richfield, MN USA 55423-3645